



Eurogaz boilers

Spare parts

Position	Description	Reference
1	Circulator 20-27 12 M (EUROGAZ)	WUN03063
	Double circuit circulator 2m³ 25/40	W49CC4
2	Primary circuit sensor (before 2004)	WUN02433
3	Pool regulation thermostat (since 95) bulb 10	WEG01404
4	Primary circuit thermometer for facade	WUN02440
5	No water pressure switch (before 2004)	WUN02441
6	Smoke safety pressure switch (CMV 24)	WUN02432
7	Electronic plate before 2002	WUN02411
8	Gas vane VK 4105 N	WUN02430
9	Lighter plate	WUN02431
10	Potentiometer heating regulation	WUN02412
11	Starter/ionisation electrode	WUN02436
12	Relay (220 V) 0006 double contacts	WCF02711
13	Relay (CMV 24) triple contacts	WCF02710
14	Noryl flow switch	WSK02022
15	Safety Klixon 105° C AE (before 2004)	WUN03060
16	Primary circuit water manometer for facade	WUN02434
17	Electric plate (CMV) from 2002	WUN03041
	1m concentric extension Ø100	WUN02415
	Protection basket	WUN02442
	Ventilator motor	WUN03066
	90° concentric angle Ø100	WUN02388
	Automatic purger	WUN02438
	Safety valve head	WUN02420
	Expansion tank one circuit (2L)	W30VASE
	Expansion tank double circuit (4L)	WIS01648
	Burner safety rearming button	WUN02445
	Boiler tank (give the model type)	W49CUVE40KT

