



| Position | Description | Reference |
|----------|---|-----------|
| \ | LM/D PCB fixing screw (M3X8 mm) | W000351 |
| \ | Insulation kit LM/D Series power PCB | W000651 |
| \ | LM/D Series PCB stand off | W001091 |
| 1 | LM/D Series barrel union DN50 mm (with Oring) | W040921 |
| | LM/D Series barrel union 1½" (with Oring, UK) | W040931 |
| 2 | LM TS 2 A replacement fuse (fits LM1 & D Series) | W110161 |
| 3 | LM2 S resetable fuse | W111071 |
| 4 | LM2-10, 15 & 24 transformer (220-240 V / 17.5 V) | W130591 |
| | LM2-40 transformer (220-240 V / 24 V) | W130421 |
| \ | LM/D Series cell cable & brass terminals | W193201 |
| \ | Empty LM2 cell housing (for after sales operations) | W200701 |
| 5 | Complete LM2-10 Cell | R0759100 |
| | Complete LM2-15 Cell | W202031 |
| | Complete LM2-24 Cell | W202051 |
| | Complete LM2-30 Cell | W202061 |
| | Complete LM2-40 Cell | W202071 |
| 6 | LM2 power PCB | W222091 |
| 7 | LM2 S control PCB | W222111 |
| 8 | LM2 TS pump supply PCB | W222131 |
| \ | LM2 S mains filter PCB | W222241 |
| 9 | LM2 TS control PCB (manufacturing date > 09/2007)* | W082741 |