




OV 3300 - OV3300 TILE

Spare parts



Position	Description	Reference
1	Float	R0539700
2	Screw 4*16mm (set of 5)	R0608500
3	Main body 2wd ii grey	R0589102
4	Flow outlet	R0517500
5	Motor screen	R0517600
6	Propeller	R0517000
7	Brush roller	R0517400
8	Roller support grey	R0518702
9	Motor block shaft pin (set of 5)	R0567800
10	Floating cable plug	R0565600
11	Tire rear black zodiac	R0636300
12	Tire large black zodiac	R0636201
13	Floating cable 15m	R0636800
14	Handle grey	R0540402
15	Rim rear grey zodiac	R0636102
16	Rim large grey zodiac	R0636003
17	Control unit type 1v	R0637300
18	Motor block type a	R0637800
19	Cover ov	R0637700
20	Wheel bushing zodiac	R0636700
21	Brush type 1 pms108 zodiac (*2)	R0635902
22	Floating cable clamp (set of 5)	R0567900
23	Drive gear (set of 2)	R0518800
24	Roller (set of 2)	R0518100
25	Fine filter v	R0636600
26	Filter canister support	R0517700
27	Transmission	R0517200
28	Cover latch grip pms108	R0638700
29	Rampe	R0519000
30	Screw 4*12 mm (set of 5)	R0516700
31	Screw 4*25 mm (set of 5)	R0638900
32	17 Gear (*2)	R0639000
33	Outer bearing (*2)	R0639100
34	Screw 2.9*9.5 Mm (set of 5)	R0639200
35	Screw 2.2*6,5Mm (*5)	R0564500
36	Control unit base	R0662600
37	Tire large tile zodiac	R0636400