



Position	Description	Reference
1	Propeller	R0517000
2	Caddy tube	R0565200
3	Caddy wheels (*2)	R0565100
4	Caddy handle	R0565000
5	Caddy accessories	R0564900
6	Caddy base	R0564800
7	Float	R0539700
8	Floating cable clamp (set of 5)	R0567900
9	Motor block shaft pin (set of 5)	R0567800
10	Floating cable plug	R0565600
11	Main housing 2wd ii	R0589100
12	Tire large ral9022 zodiac	R0636200
13	Tire rear ral9022 zodiac	R0636301
14	Handle blue	R0540400
15	Rim large pms2915 zodiac	R0636002
16	Rim rear pms2915 zodiac	R0636101
17	Wheel bushing zodiac	R0636700
18	Floating cable 18m	R0516800
19	Brush type 1 pms2915 zodiac (*2)	R0635901
20	Drive gear (set of 2)	R0518800
21	Roller (set of 2)	R0518100
22	Fine filter v	R0636600
23	Filter canister support	R0517700
24	Remote control holster	R0548500
25	Brush roller	R0517400
26	Transmission	R0517200
27	Flow outlet	R0517500
28	Motor block type b	R0637900
29	Motor screen	R0517600
30	Roller support	R0518700
31	Screw 4*16mm (set of 5)	R0608500
32	Remote control w/o ls zodiac	R0637600
33	Control unit type 6v	R0637400
34	Hood pms2915 spoiler	R0718700
35	Rampe	R0519000
36	Cover latch grip pms108	R0638700
37	Screw 4*12 mm (set of 5)	R0516700
38	Screw 4*25 mm (set of 5)	R0638900
39	17 Gear (*2)	R0639000
40	Outer bearing (*2)	R0639100
41	Screw 2.9*9.5 Mm (set of 5)	R0639200
42	Screw 2.2*6,5Mm (*5)	R0564500