


# RV 4310 TILE

Spare parts



| Position | Description                      | Reference |
|----------|----------------------------------|-----------|
| 1        | Float                            | R0539700  |
| 2        | Screw 4*16mm (set of 5)          | R0608500  |
| 3        | Main housing 2wd ii              | R0589100  |
| 4        | Flow outlet                      | R0517500  |
| 5        | Motor screen                     | R0517600  |
| 6        | Propeller                        | R0517000  |
| 7        | Brush roller                     | R0517400  |
| 8        | Roller support                   | R0518700  |
| 9        | Motor block shaft pin (set of 5) | R0567800  |
| 10       | Floating cable plug              | R0565600  |
| 11       | Tire rear black zodiac           | R0636300  |
| 12       | Tire large tile zodiac           | R0636400  |
| 13       | Floating cable 18m               | R0516800  |
| 14       | Handle blue                      | R0540400  |
| 15       | Rim rear r9022 zodiac            | R0636100  |
| 16       | Rim large r9022 zodiac           | R0636001  |
| 17       | Control unit type 5v             | R0637300  |
| 18       | Motor block type a               | R0637800  |
| 19       | Hood blue                        | R0544700  |
| 20       | Wheel bushing zodiac             | R0636700  |
| 21       | Zodiac brush (set of 2)          | R0635900  |
| 22       | Floating cable clamp (set of 5)  | R0567900  |
| 23       | Drive gear (set of 2)            | R0518800  |
| 24       | Roller (set of 2)                | R0518100  |
| 25       | Fine filter v                    | R0636600  |
| 26       | Filter canister support          | R0517700  |
| 27       | Transmission                     | R0517200  |
| 28       | Cover latch grip pms108          | R0638700  |
| 29       | Rampe                            | R0519000  |
| 30       | Screw 4*12 mm (set of 5)         | R0516700  |
| 31       | Screw 4*25 mm (set of 5)         | R0638900  |
| 32       | 17 Gear (*2)                     | R0639000  |
| 33       | Outer bearing (*2)               | R0639100  |
| 34       | Screw 2.9*9.5 Mm (set of 5)      | R0639200  |
| 35       | Screw 2.2*6,5Mm (*5)             | R0564500  |
| 36       | Caddy handle                     | R0565000  |
| 37       | Caddy tube                       | R0565200  |
| 38       | Caddy wheels (*2)                | R0565100  |
| 39       | Caddy accessories                | R0564900  |
| 40       | Caddy base                       | R0564800  |