



Position	Description	Reference
1	Float	R0539700
2	Screw 4*16 mm (set of 5)	R0608500
3	Main body 2wd ii white	R0589101
4	Flow outlet	R0517500
5	Motor screen	R0517600
6	Propeller	R0517000
7	Brush roller	R0517400
8	Roller support white	R0518701
9	Motor block shaft pin (set of 5)	R0567800
10	Floating cable plug	R0565600
11	Tire rear ral9022 zodiac	R0636301
12	Tire large ral9022 zodiac	R0636200
13	Floating cable 18m	R0516800
14	Handle ral9022 ls	R0636501
15	Rim rear pms2915 zodiac	R0636101
16	Rim large pms2915 zodiac	R0636002
17	Control unit type 1v	R0636900
18	Motor block type a	R0637800
19	Cover rv4460	R0638200
20	Wheel bushing zodiac	R0636700
21	Brush type 1 pms2915 zodiac (*2)	R0635901
22	Floating cable clamp (set of 5)	R0567900
23	Drive gear (set of 2)	R0518800
24	Roller (set of 2)	R0518100
25	Fine filter v	R0636600
26	Filter canister support	R0517700
27	Transmission	R0517200
28	Cover latch grip pms108	R0638700
29	Rampe	R0519000
30	Screw 4*12 mm (set of 5)	R0516700
31	Screw 4*25 mm (set of 5)	R0638900
32	17 Gear (*2)	R0639000
33	Outer bearing (*2)	R0639100
34	Screw 2.9*9.5 Mm (set of 5)	R0639200
35	Screw 2.2*6,5 Mm (*5)	R0564500
36	Caddy handle	R0565000
37	Caddy tube	R0565200
38	Caddy wheels (*2)	R0565100
39	Caddy accessories	R0564900
40	Caddy base	R0564800